Engine/Transmission Mounting Positions

Unit: mm (in)

Ⓒ、Ⓒ'
FRONT SIDE FRAME
POINT 20 (0.8)



Ⓗ
ENGINE SIDE MOUNT
SUPPORT POINT 13 (0.5)



Ⓘ
TRANSMISSION MOUNT
BRACKET POINT 15 (0.59)



All except V-6 engine model:



V-6 engine model:

Ⓗ
ENGINE SIDE MOUNT
SUPPORT POINT 13 (0.5)